

STANDARD QWERTZU ROM FOR GERMANY

INSTALL PROCEDURE

- 1) Remove the RAM/ROM compartment cover.
- 2) Put the printed EPROM board in the biggest socket (M11).
Be sure that the pin 1 of the printed circuit matches with the one of the socket.
- 3) Close the cover.
- 4) Power the computer ON and type from BASIC: **CALL 63012**
- 5) To activate the drivers and access to the menu, retype: **CALL 63012**
To execute this step, the QWERTZU EPROM must absolutely be in the M11 socket.
- 6) A menu is displayed which allows you to choose the type of printer output :
Dot Matrix, Daisy Wheel New Pitch 10-12, Daisy Wheel Old.
The QWERTZU keyboard is also activated by point 6).
Each time you want to modify the printer relation, execute point 6).

USE OF MULTIPLAN.

If you want to use the QWERTZU driver with Multiplan, after you have executed point 6), go to BASIC and type: **POKE 63018,255 <ENTER>**

Power the computer off and replace the QWERTZU ROM by the Multiplan one.

Go to BASIC and type : **CALL 32237**

Then, type : **CALL 32784 <ENTER>** on a 32K.

or **CALL 40976 <ENTER>** on a 24K.

Each time you want to select an other printer, you have to type from BASIC:

CALL 32784 <ENTER> on a 32K.

CALL 40976 <ENTER> on a 24K.

IMPORTANT : Don't remove the Multiplan ROM because you will loose all your files.